



Download the FREE
FROG® Water Care® App



Water Balance Guide for Hot Tubs or Swim Spas

How to get
your water
relaxation
ready!

BEFORE YOU BALANCE - TEST YOUR FILL WATER

STEP 1 FOR TOTAL HARDNESS


Take a sample of the water you plan to use to fill your hot tub or swim spa to your dealer and check for Total Hardness. If over 250 ppm, don't use that water to fill your hot tub! A simple hose filter from your local dealer can solve your issue.

STEP 2 FOR METALS

If it tests high for metals, use a metal out product.

4 TIPS FOR SUCCESSFUL WEEKLY WATER BALANCING

- 1 ALWAYS BALANCE IN ORDER WITH STEP 1: TOTAL ALKALINITY, THEN STEP 2: pH, AND THEN STEP 3: RECHECK TOTAL HARDNESS.



- 2 ADD ADJUSTMENT CHEMICALS IN SMALL INCREMENTS (FOLLOW LABEL DIRECTIONS CAREFULLY).
- 3 WAIT 6 HOURS BETWEEN ADJUSTMENTS SO YOUR ADJUSTMENT CHEMICAL HAS TIME TO WORK.
- 4 IF BALANCING TAKES LONGER THAN 2 DAYS, ADD A CHLORINE SHOCK TO MAINTAIN SANITIZER LEVELS.

When Total Alkalinity is 80-120 ppm, pH is 7.2-7.6 and Total Hardness is 150-250 ppm, your water is balanced.